

BANGOR PUNTA MARINE
848 AIRPORT ROAD
FALL RIVER, MA 02722
(617) 678-5291

**BANGOR
PUNTA
MARINE**

HALYARD WINCH INSTALLATION INSTRUCTIONS

O'DAY 25, O'DAY 23, O'DAY 22, O'DAY 19, MARINER

<u>Kit Contains</u>	<u>Model</u>	<u>Part #</u>	<u>Quantity</u>
Halyard Winch	O'DAY 25/23/22/MAR.	23307	1
Winch Base	O'DAY 25/23/22	23314	1
Base Plate	MARINER	23303	1
Winch Handle	O'DAY 25/23/22/MAR.	23318	1
1/4" x 1" Machine Screws	O'DAY 25/23/22/MAR.	60600	4

Instructions

- 1) Disassemble the winch by removing the large ring located on the top of the winch.
- 2) Place the bottom section of the winch over the winch base (with the side facing down). Using the screw holes as guides, drill (with a 1/4" drill) through the winch base. (Do not drill on mast).
- 3) Locations:
 - O'DAY 25 - 33 1/2" from the base of the mast to the top of the winch base. *
 - O'DAY 23 - 3' from the base of the mast to the top of the winch base. (Standard 1976 and on). *
 - O'DAY 22 - 28" from the base of the mast to the top of the winch base. *
 - O'DAY 19 - 29" from the base of the mast to the top of the winch base. *
 - MARINER - 29" from the base of the mast to the top of the winch base. *
- 4) Using the screw holes as guidelines, drill the 4 holes into the mast. *
- 5) Insert the screw through the bottom part of the winch, through winch base, into mast, and tighten. You can now re-assemble the winch.

* Use 7/32" drill bit.

JS/ndm
3/19/79